

## Leatherette / Suede Seat Bottom Cover Installation Instructions

For model numbers PV001-BOTTOM, PV005-BOTTOM, PV006-BOTTOM, PV007-BOTTOM

Always wear gloves to protect your hands from any sharp edges under seat and eye protection to protect from straps that may snap back if suddenly released



View installation video  
[youtu.be/ptk909pUIRE](https://youtu.be/ptk909pUIRE)



PDF version of this document  
[autohq.com/pvbottom.aspx](https://autohq.com/pvbottom.aspx)



More installation resources  
[autohq.com/install.aspx](https://autohq.com/install.aspx)

### Seat Bottom Cover


Has 8 nylon straps, 6 with buckles ("A", "B", "D") and 2 with Velcro ("C")



## Step A - Prepare Your Seat


Seats do not need to be removed from vehicle in order to install seat covers. Photos are for illustration purposes only and may vary from your actual seats.

1. Raise seat bottom up as high as possible using controls on side of seat, if equipped with this feature. This will make it easier to reach underneath seat to install straps.
2. Increase space in the gap between the backrest and seat bottom by tilting the backrest forward, in the direction of the vehicle's dashboard, as you would to allow a passenger into the backseat of a 2-door vehicle.
3. Check for presence of flaps that cover the gap between the backrest and seat bottom by viewing seat from behind, as a passenger would when sitting in the back seat. If the gap between the seat backrest and seat bottom is not visible, cannot be located by feeling around, or you cannot push your fingers from the front to the back through the gap, then your seat has a flap. Flap must be opened by unhooking or unclipping it from underneath seat bottom before cover can be installed and can be replaced once installation is complete. **Not all vehicles have these flaps.**



## Step B – Install Seat Bottom Cover

1. Place seat bottom cover over seat with pocket facing the front of seat where your knees would be and tongue with straps "A" at the back.




2. Cap the front portion of the cover over the front of the seat. Insert the tongue and 2 rear straps "A" through the gap with the backrest. Tuck sides of cover and 2 side straps "C" through plastic molding on side of seat. *Side straps "C" are designed to go between the seat cushion and plastic molding leaving seat controls accessible, not over the plastic molding.*



If buckles are off straps: Straps "B" come with the 3-prong portion of the buckle that reattach easily. The top of the buckle has 2 openings while the bottom has 1 larger opening. From the bottom, feed strap up through opening then back down through the second opening. Adjust the location of buckle on strap and tighten by holding buckle and tugging on portion of strap that was used to feed into bottom.



3. From behind the seat, tug on tongue firmly until cover is secure and does not slide. Then from underneath the seat, buckle back straps "A" to longer front straps "B". Adjust and tighten as necessary by tugging on the loose ends of straps "B". Connect 2 side straps with Velcro "C" to each other as tight as possible. Shorter front straps "D" are for the backrest portion of the cover that is sold separately. All straps should be secured above any wiring, electric motors or rails, as close as possible to actual seat cushion itself, keeping straps as flat and parallel as possible to the vehicle's floorboard. Any open seat flaps (from step A3) can be reconnected at this time.



## Frequently Asked Questions

My covers came with markings / depressions / wrinkles on them, is this a defect? – This is perfectly normal. The markings are due to the covers being in the box used to ship to you. Like a mattress or a mattress pad that comes in a box, the markings will fade over time once the covers are installed. Markings fade faster in the summer when the interior of your vehicle is hotter.

My installed seat cover is not flush to the seat – No worries, seat cover will shape itself to seat over time as it is sat in.

## Common Installation Issues

Nowhere to connect straps – Your seat covers have straps that are designed to hook/connect to the underside of your vehicle's seat bottom. If they are on the top, then the cover is upside down.

No opening to pass straps through to seat bottom – Many vehicles have flaps that cover the gap in the seat (where the back rest and seat bottom come together) that have to be opened to allow the seat cover straps access to the underside of the seat bottom. To do this, look for clips or hooks on the

underside of the seat that hold the flap in place then unhook them so that the flap opens. Install the seat cover, pushing the straps through the gap of the seat and then securing them underneath the seat. Finally, replace the flap clips on the underside of the seat.

Straps too short / straps keep loosening / slippage – Side straps must enter the gap between the seat bottom cushion and the plastic molding for a proper fit, with any excess seat cover material tucked in. Install straps above any rails or electric seat motors, that is, as close as possible to the underside of the seat bottom without looping over any of these parts. Clip or Velcro corresponding straps together and tension the straps as tight as possible by pulling them to pick up excess slack. Straps that are installed under an electric motor will eventually loosen with the readjusting of the seat position. Will not harm any seat electronics.

Controls on side of seat bottom are not accessible – Straps go between the seat cushion and plastic molding, not over.

Leg extensions of sport seats do not extend – Only custom-made covers allow for leg extension movement.

## **Care and Cleaning - Varies by Material**

Leatherette – Easy clean up by just wiping down with a damp cloth, Simple Green or leather cleaner for car interiors.

Suede – Spot clean with water and mild soap.

## **Still Need Help?**

Call us at (888) 288-6471 x2 for assistance. Video call available through FaceTime, WhatsApp, Skype

## **Happy with the results?**

We'd love to see a photo! You can text to us at 619-752-4584 or email to [sales@autohq.com](mailto:sales@autohq.com)



We'd appreciate your positive review on Google.